

Become an expert of your Fibro spa! Learn all there is to know about the maintenance of your spa by clicking the different sections in the menu in the left column.

Emptying the spa

SPA1 Above-Ground

Empty the SPA with a submersible pump.

SPA II

Empty the SPA by opening the drain valve installed at the base of the pump or the water heater. This valve is designed to connect to a garden hose.

Inground SPA I, SPA III, SPA F-17

Before emptying an inground SPA, it is very important that you verify if there is a body of water that could lift the SPA out of position. Remove the cover of the dewatering well and check if there is water present in the well. Using a submersible pump, remove any water in the well.

- 1- Open the cover of the skimmer and remove the basket.
- 2- Place the skimmer valve lever in the horizontal position and pivot the white cover over the top hole of the valve.
- 3- Connect a hose to the drain valve and extend the hose towards the street so that the water does not return back to the SPA.
- 4- Turn the valve lever to the drain mode
- 5- Let the water from A GARDEN hose flow feebly through the skimmer. This is to prevent unpriming the pump once the water level reaches the base of the skimmer.

Filter Cleaning

It is highly recommended that the cartridge be cleaned with a garden hose under pressure once a week, preferably 24 hours after adding the clarifying agent.

A cartridge that is not cleaned properly can build up pressure in the filter element, which could result in damaging the cartridge itself

When changing the water in the Spa every 10 to 12 weeks, it is quite important to soak the cartridge in a solution recommended for this purpose: 3 parts water for 1 part Javel water. Rinse well and let dry. This will increase the life expectancy of the cartridge.

Spa Opening

In order to guarantee its reliability and your long-term satisfaction, your FIBRO SPA has been tested in-plant by a certified technician.

Make sure that the electrical hookup has been performed by a Master Electrician.

Once the SPA has been filled to its appropriate level, press the HEAT button and set the temperature.

Chemically test your water. Balance your water and add the necessary chemical products by carefully following the instructions supplied by your manufacturer.

Digital keyboard controls

To Start The Pump

Press the JETS button once to start the pump, press twice to change the speed and a third time to stop the pump. The pump will stop automatically after 20 minutes unless you have deactivated it manually. When the pump is ON, the pilot lamp (pump) is lit.

Water Temperature:

Press the UP/DOWN button and hold it in to increase the temperature of the water. Press a second time and hold it in to reduce the temperature. To confirm the setting, the desired temperature will be displayed for 5 seconds.

To Turn On The Light:

Press the LIGHT button to turn on the light and press again to turn it off.

Water Heater – Automatic Start:

When the water temperature reaches 1° below the desired temperature, the water heater starts automatically until the water temperatures exceeds the desired temperature by 1°.

To Program The Length Of The Filtration Cycle

Press the LIGHT button for 5 seconds. The screen will display the actual length of the filtration cycle in hours. Press the UP/DOWN button to set the length of the cycle in hours. Example: 0 = no filtration and 12 = continuous filtration. When the desired time appears, press the LIGHT button to confirm.