

MAINTENANCE OF THE CARTRIDGE

It is highly recommended to clean the cartridge of your filter **once a week**.

Simply rinse the cartridge using a garden hose.

A poorly cleaned cartridge will cause a low pressure in the heater affecting the system operation and may damage the cartridge itself.



When changing spa water, approximately every ten to twelve weeks (depending on use), it is important to soak the cartridge in a solution recommended for this purpose (three parts of water- one part of bleach). Then rinse your cartridge.

To increase durability and longevity of your cartridge, we recommend you let your filter dry before reinstalling.