





























## *Steps to follow: inground SPA-3*

**ALWAYS VERIFY THE WATER LEVEL IN THE DRAINING WELL  
BEFORE LOWERING THE WATER LEVEL OF YOUR SPA.**

		<p>Lower water level below whirlpool jets. (Photo 1-2)</p>
		<p>To do so, place the red lever on the skimmer valve in the horizontal position and pivot the cover over the top hole of the valve. (Photo 3)</p>
		<p>Unroll the drain hose towards the street so the water doesn't return towards the SPA. (Photo 4)</p>
		<p>Turn the valve handle on the pump towards the <b><u>drain position</u></b>.</p> <p>To do so, slightly loosen the nut on the lever's valve. (Photo 5). Then, place the lever's valve to a horizontal position pointing towards the cartridge system, this is the draining position. (Photo 6: Drainage).</p>
		<p>Let flow the garden hose into the skimmer. (Photo 7). This step is to prevent unpriming the pump when the water reaches the base of the skimmer.</p>
		<p>Once the water level is lowered, remove the electrical feed to the pump.</p> <p>Remove the drain stopper at the base of the cartridge filter. (Photo 8).</p> <p>Once the cartridge system is drained, remove the cartridge from the filter and store it.</p>
		<p>Remove the 2 drain stoppers from the pump. (Photo 9 and 10).</p>
		<p>Unplug the suction from the pump (Photo 11) and return rings going towards the filter (towards the SPA). (Photo 12)</p>
		<p>Unscrew the inside of the whirlpool jets with the appropriate Fibro tool. (Photo 14 and 15).</p>

 <p>16</p>	 <p>17</p>	<p>Close the air vents. (Photo 16). With a Shop Vac or an air compressor, blow air through the filtration system's return pipe (Photo 17) until water has drained from the whirlpool jets. Ensure that air escapes from each jet.</p>
 <p>18</p>	 <p>19 a</p>  <p>19 b</p>	<p>Once the water's all drained from the return pipe, insert winterising caps in each jet. (Photo 19 a- or 19-b)</p> <p>Unscrew air vents, pour 1 litre of antifreeze inside each one of them and make sure to screw them back when you are finish. (Photo 18).</p>
 <p>20</p>		<p>Blow air through the waterfall pipes, if applicable.</p> <p>Remove the skimmer valve by unscrewing the 2 screws. (Photo 20: violet).</p>
 <p>21</p>	 <p>22</p>	<p>Before draining the suction pipe, <b>temporarily</b> block the hole nearest the SPA inside the skimmer (Photo 22) with a cap. (Photo 21). This will prevent water from the bottom drain from returning towards the skimmer, allowing you to drain the bottom of the skimmer.</p>
 <p>23</p>		<p>With you Shop Vac, suck the water out at the bottom of the skimmer and in the other hole. This way, the suction pipe will be completely drained up to the front of the motor. (Photo 23)</p>
 <p>24</p>	 <p>25</p>	<p>With Teflon on its threads, screw the Gizmmo unit in the skimmer suction hole (the one furthest away from the SPA) (Photo 24 and 25)</p>
 <p>26</p>		<p><b>Remove the cap</b> (Photo 21) temporarily installed at the bottom of the skimmer. It is normal if water, through the action of gravity, reappears at the bottom of the skimmer. Pour about 2 litres of antifreeze into the skimmer until it seeps from the drain. (Photo 26)</p>
 <p>27</p>	 <p>28</p>	<p>Insert polystyrene strand as far as possible in the drain hole at the bottom of the skimmer. Tie a knot at one end to prevent the strand from coming out. (Photo 27 and 28)</p> <p><b>*** Pour terminer, recouvrir étanchement le moteur, le Spa-pack et le système de filtration à cartouche afin de les garder à l'abri des intempéries hivernaux.</b></p> <p>If necessary, you can put a leaf net on your SPA to prevent dirt and leaves from falling into the water.</p>
		<p><b>Important:</b> if your SPA is closed and there is a lot of precipitation <i>check the draining well again.</i> If necessary, empty the well with a <b>submersible pump.</b></p> <p>Never reduce water level in the SPA after it has been closed, without checking the draining well beforehand</p>